# **BTS-32MK2**


### Instruction Manual


### www.denver-electronics.com

Before operating this product, please read this instruction manual completely for optimal usage.



## **Function Keys:**





Vol-/Previous song

#### 1.ON/OFF

Silde ON/OFF switch to the right to power on and slide ON/OFF to the left to power off.

#### 2.Bluetooth Connection

Follow the operating instruction of your Bluetooth deivce for pairing with the speaker. When pairing, use cell phone or computer or other device seach device name "Denver BTS-32", clip to connect and then can connect successfully.

#### Button icon:

#### 1, Mode icon:

achieve bluetooth mode and TF card music playing , lighting mode changing freely

#### 2,Bluetooth music mode:

Short press " < " to play the next song and long press to volume up.

Short press " > " to play the previous song and long press to volume down.

#### 3, Hands free calling:

Answer and hang up the phone:

There will be an alert sound from the speaker when there is a phone call. Click " [] "

to answer the call, and click" [>" again to hang up .

#### 4, music playing:

Finter MicroSD Card music playing mode automatically when MicroSD Card inserted

Short press " < " to play the next song and long press to volume up.

Short press " > " to play the previous song and long press to volume down.

Music playing or pause by click

Fluetooth mode will switch by click the MODE button when on MicroSD Card music playing mode

ALL RIGHTS RESERVED, COPYRIGHT DENVER ELECTRONICS A/S



www.denver-electronics.com



Electric and electronic equipment and included batteries contains materials, components and substances that can be hazardous to your health and the environment, if the waste material (discarded electric and electronic equipment and batteries) is not handled correctly.

Electric and electronic equipment and batteries is marked with the crossed out trash can symbol, seen below. This symbol signifies that electric and electronic equipment and batteries should not be disposed of with other household waste, but should be disposed of separately.

As the end user it is important that you submit your used batteries to the appreciate and designated facility. In this manner you make sure that the batteries are recycled in accordance with legislature and will not harm the environment.

All cities have established collection points, where electric and electronic equipment and batteries can either be submitted free of charge at recycling stations and other collection sites, or be collected from the households. Additional information is available at the technical department of your city.

Hereby, Inter Sales A/S declares that the radio equipment type BTS-32MK2 is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: Please enter: <a href="www.denver-electronics.com">www.denver-electronics.com</a> and then click the search ICON on topline of website. Write modelnumber: BTS-32MK2

Operating Frequency Range: 2402MHz-2480MHz

Max Output Power: 20dBm

DENVER ELECTRONICS A/S Omega 5A, Soeften

DK-8382 Hinnerup Denmark

www.facebook.com/denverelectronics