Quick start guide

Connecting power: Connect the included Micro USB cable to the Micro USB port on the backside of the main unit.

Your clock has a battery backup feature, Place 2 x AAA batteries into the compartment.

Radio:

- 1. Press Touch Button Lock on the backside of the unit to unlock the touch button.
- 2. Press the "**'**/RADIO/AL OFF" to turn the radio on, and press the "HOUR/TUN-" or "MIN/TUN+" button to adjust frequency.
- 3. Press and hold "TIME/PRESET" button until "P01" (or the next available preset) shows on the display.
- 4. Press the "HOUR/TUN-" or "MIN/TUN+" button to select a preset number (P01-P10), then press the "TIME/PRESET" button to confirm.
- 5. Press the "TIME/PRESET" button repeatedly while listening to the radio to select a preset station.
- 6. Press Touch Button Lock on the backside of the unit to lock the touch button.

SETTING THE TIME

- 1. Press Touch Button Lock on the backside of the unit to unlock the touch button.
- 2. In standby mode, press and hold the "TIME/PRESET" button to enter the clock setting mode.
- 3. Press the "HOUR/TUN-" and "MIN/TUN+" to select hours and minute, then press "TIME/PRESET" button to confirm.
- 4. Press Touch Button Lock on the backside of the backside of the unit to lock the touch button.

SETTING THE ALARM

- 1. Press Touch Button Lock on the backside of the unit to unlock the touch button.
- 2. In standby mode, press and hold the "AL1/VOL-" or "AL2/VOL+" button to enter the alarm time setting mode.
- 3. Press "HOUR/TUN-" to set the hour and "MIN/TUN+" button to set the minute then press "AL1/VOL-" or "AL2/VOL+" button to confirm.
- 4. Press Touch Button Lock on the backside of the unit to lock the touch button.

QI WIRELESS CHARING

- 1. Place your Qi enabled smartphone on the center of the wireless charging pad. The Wireless Charging Indicator on display will be on.
- 2. Please check if your phone screen shows charging status If your phone is not charging;
 - Check if your device supports Qi wireless charging
 - Place mobile device in center
 - Remove the case with magnet, metal, or thicker material than 0.12"(3mm)